








## TUFWAY UNIT ACCESSORY LOCATIONS

The following will be the standard locations for accessories when assembled by Satellite Industries




<b>Location "A"</b>	<p><b>PAPERGUARD</b> Right panel, see Tufway unit assembly instructions P/N 10900.</p>	<p><b>2 PAPERGUARD PER UNIT</b> Right panel, mount lower paperguard see unit assembly instructions P/N 10900. Mount upper paperguard 2 ¼" directly above lower paperguard.</p>	<p><b>3 ROLL PAPERGUARD</b> Right panel, see 3 roll paperguard installation instructions P/N 18142</p>
			

<b>Location "B"</b>	<p><b>PAPERGUARD WITH SLIMMATE II</b> Left panel, between vent pipe &amp; rear panel in line with 4 dimples (same height). Measure 4-1/2" over towards rear panel from top left dimple of four dimples in left panel. Mark through top left hole in paperguard and drill at mark using ¼" drill bit. Install rivet through top left hole in paperguard into hole in panel &amp; install push cap and/or rivet from outside of panel. Mark 3 remaining holes (make sure paperguard hood is level) in paperguard. Swing paperguard up out of the way &amp; drill at 3 marks in left panel. Install push caps and/or rivets.</p>	<p><b>PAPERGUARDS /2 PER UNIT WITH SLIMMATE II</b> Mount lower paperguard in the same location as unit with Slimmate II with single paperguard. Mount upper paperguard 2" directly above lower paperguard.</p>
		

<b>Location "C"</b>	<p><b>PAPERGUARD/WITH SLIMMATE II</b> Right panel, logo area</p>	<p><b>3 ROLL PAPERGUARD / WITH SLIMMATE II</b> Right panel, see 3 roll paperguard installation instructions P/N 18142</p>
		

## TUFWAY UNIT ACCESSORY LOCATIONS

<b>Location "A"</b>	<b>HAND SANITIZER / SOAP DISPENSERS</b> Right facing (hasp side) on inside of front (centered), 61" to top hole from floor. See #18432	<b>Location "B"</b>	<b>HAND SOAP/SANITIZER DISPENSERS</b> Left Panel over the Urinal (centered), 61" to top hole from floor. See #18432
			

<b>Location other options</b>	<b>SLIMMATE II</b> Right front corner of unit. Mount per Slimmate II installation instructions P/N 16364.	<b>SHELF</b> Right rear corner, see shelf installation instructions P/N 17455.	<b>PAPER TOWEL DISPENSER</b> Rear panel, see paper towel dispenser installation instructions P/N 12798.
			

<b>Location other options</b>	<b>HOVER HANDLE</b> Inside of door, see hover handle installation instructions P/N #18459	<b>MIRROR</b> Inside of door, see mirror installation instructions P/N 17936.
		



SATELLITE INDUSTRIES, INC.

2530 Xenium Lane North, Minneapolis, MN 55441  
 Telephone: 763-553-1900 Fax: 763-553-1905  
 800-328-3332 / [www.satelliteindustries.com](http://www.satelliteindustries.com)